

HAMADA 775/E-47S OLD STYLE SATELLITE

Frequently Used Part Numbers

Rollers

| | |
|--------------|---|
| X07-0114 | Form Roller, Soft |
| X07-0313NS | Pan Roller, Soft |
| X07-0413 | Oscillator Roller, Hard |
| XSA-070214NS | Metering Roller Assy., Hard (Roller, shaft, E-clips) |

Side Frame Assemblies

| | |
|------------|---|
| XSA-010113 | OPS Side Frame Assy. (Side frame w/ bearings) |
| XSA-010114 | NOPS Side Frame Assy. (Side frame w/ bearings) |

Gears

| | |
|--------------|--|
| XSA-03211538 | Form Gear Assy. (Gear w/ clutch bearing) |
| XSA-03211530 | Pan Gear Assy. (Gear w/ clutch bearing) |
| XSA-032115HM | Idler Gear Assy. (Gear, bearing, shoulder bolt) |


Side Frame Bearings

| | |
|-----------------------------|---|
| (After serial #9111-08613) | |
| X06-108 | Sealed Ball Bearing, Side Frame (4 per dampener) |
| (Before serial #9111-08613) | |
| X06-346038 | Thin Flanged Bushing (4 per dampener) |

Miscellaneous

| | |
|----------|--|
| XSA-9999 | Metering Thumb Screw Assy. (Thumb screw, ratchet gear, set screw) |
| X09-0101 | Compression Spring (2 per dampener) |
| XSA-1116 | Water Pan Assy. (w/ pan bolts) |
| X99-61 | Wash Up Bottle |
| X88-26 | Installation Manual |

**FAX YOUR ORDER
TO ACCEL TOLL FREE!
1 (800) 365-6510**



Adjustments

- a. Metering to Pan
- b. Form to Metering
- c. Form to Plate

Roller Description

- P = Pan, Soft
- M = Metering, Hard
- O = Oscillator, Hard
- F = Form, Soft