

# HAMADA C252

## Frequently Used Part Numbers

### Rollers

X07-0146	Form Roller, Soft
X07-0354	Pan Roller, Hard
X07-0448	Oscillator Roller, Hard
XSA-070220SC	Metering Roller Assy., Soft (Roller, shaft, bearings, snap rings)
XSA-0705150SC	Intermed. Roller Assy., Soft (Roller, shaft, bearings, collars)
X07-0603	Rider Roller

### Gears

XSA-03231535	Pan Gear Assy. (Gear w/ clutch bearing)
XSA-03231526	Narrow Idler Gear Assy. (Gear, bearing, shoulder bolt)
XSA-03212526	Wide Idler Gear Assy. (Gear w/ 2 ball bearings)

### Sealed Ball Bearings


X06-111	Sealed Ball Bearing, Side Frame (2 per dampener)
X06-112	Sealed Ball Bearing, Pan Roller (2 per dampener)

X06-113 Sealed Ball Bearing, Water Form  
(2 per dampener)

### Miscellaneous

XSA-1144	Water Pan
X99-90	Water Pan Bolts, Short (2 per water pan)
X99-61	Wash Up Bottle
X88-88	Installation Manual

**FAX YOUR ORDER  
TO ACCEL TOLL FREE!  
1 (800) 365-6510**



#### Adjustments

- a. Metering to Pan
- b. Metering to Intermediate
- c. Intermediate to Oscillator
- d. Oscillator to Form
- e. Form to Plate
- f. Auxiliary Rider to Form

#### Roller Description

P	=	Pan, Hard
M	=	Metering, Soft
I	=	Intermediate, Soft
O	=	Oscillator, Hard
F	=	Form, Soft
A	=	Auxiliary Rider