

TOKO 4700

Frequently Used Part Numbers

Rollers

X07-0111	Form Roller, Soft
X07-0310	Pan Roller, Hard
X07-0415	Oscillator Roller, Hard
XSA-070211	Metering Roller Assy., Soft (Roller, shaft, bearings, collars)
XSA-070506	Intermed. Roller Assy., Soft (Roller, shaft, bearings, collars, roll pin)

Side Frame Assemblies

XSA-0108TKO	OPS Side Frame w/ Bearings
XSA-0108TKN	NOPS Side Frame w/ Bearings

Gears

XSA-03221538	Form Gear Assy. (Gear w/ clutch bearing)
XSA-03221526	Pan Gear Assy. (Gear w/ clutch bearing)
XSA-03221520	Upper Idler Gear Assy. (Gear, bushing, shoulder bolt)
XSA-03221526X	Lower Idler Gear Assy. (Gear, bushing, spool, washers, bolt)

Bearings


(After Serial number 9304-09982)	
X06-108	Sealed Ball Bearing, Side Frame (4 per dampener)
(Before Serial number 9304-09982)	
X06-346038	Thin Flanged Bushing, Side Frame (4 per dampener)
X06-324031	Flanged Bushing (2 per dampener)
X06-103	Sealed Ball Bearing, Pivot (2 per dampener)

Miscellaneous

XSA-9903	Metering Thumb Screw Assy. (Thumb screw, ratchet gear, set screw)
X09-0101	Compression Spring (2 per dampener)
XSA-1112	Water Pan Assy. (w/ pan bolts, water bottle bracket)
X99-28	Water Pan Hose
XSA-9905	Water Bottle (w/ cap)
X99-61	Wash Up Bottle
X88-34	Installation Manual

FAX YOUR ORDER
TO ACCEL TOLL FREE!
1 (800) 365-6510

Adjustments
a. Metering to Pan
b. Form to Plate



Roller Description
P = Pan, Hard
M = Metering, Soft
I = Intermediate, Soft
O = Oscillator, Hard
F = Form, Soft

TOKO 4750

Frequently Used Part Numbers

Rollers

X07-0129	Form Roller, Soft
X07-0331NS	Pan Roller, Soft
X07-0414A	Oscillator Roller, Hard
X07-0204NS	Metering Roller, Hard
XSA-0705ZZ	Intermed. Roller Assy., Soft (Roller, shaft, collars, roll pin)

Side Frame Assemblies

XSA-0108TKO	OPS Side Frame w/ Bearings
XSA-0108TKN	NOPS Side Frame w/ Bearings

Gears

XSA-03221538	Form Gear Assy. (w/ clutch bearing)
XSA-03221526	Pan Gear Assy. (w/ clutch bearing)
XSA-03221520	Upper Idler Gear Assy. (Gear, bushing, shoulder bolt)
XSA-03221526X	Lower Idler Gear Assy. (Gear, bushing, spool, washers, bolt)


Bearings

(After Serial number 9304-09982)	
X06-108	Sealed Ball Bearing, Side Frame (4 per dampener)
(Before Serial number 9304-09982)	
X06-346038	Thin Flanged Bushing, Side Frame (4 per dampener)
X06-324031	Flanged Bushing, Side Frame (2 per dampener)
X06-103	Sealed Ball Bearing, Pivot (2 per dampener)

Miscellaneous

XSA-9903	Metering Thumb Screw Assy. (Thumb screw, ratchet gear, set screw)
X09-0101	Compression Spring (2 per dampener)
X99-28	Water Pan Hose
XSA-9905	Water Bottle (w/ cap)
X99-61	Wash Up Bottle
X88-34	Installation Manual

FAX YOUR ORDER
TO ACCEL TOLL FREE!
1 (800) 365-6510



Adjustments

- a. Metering to Pan
- b. Form to Plate

Roller Description

P	=	Pan, Soft
M	=	Metering, Hard
I	=	Intermediate, Soft
O	=	Oscillator, Hard
F	=	Form, Soft